



 **LISYclock**
v2.03 05/2026
www.lisy.dev

To adjust WiFi credentials to your home network connect clock to USB on your PC and use the provided config editor.
More documentation on <https://lisy.dev/lisyclock.html>

USB-C
5V power & prpb

Micro SD card >
"config.txt"

loudspeaker

RTC modul

S1 71P223
S2 71P223

LISY
development

3V

CH340C

reset

options

wifi off

ethernet on

sound on

AMS1117 3.3

DS3231

MA90337A

IC1

IC2

IC3

IC4

IC7

DS24

DS24

DS14

DS14

DS8

DS8

DS3

DS3

DS9

DS9

DS12

DS12

DS16

DS16

DS7

DS7

DS2

DS2

DS1

DS1

DS4

DS4

DS18

DS18

DS19

DS19

DS22

DS22

DS3

DS3

DS4

DS4

DS5

DS5

DS6

DS6

DS7

DS7

DS8

DS8

DS9

DS9

DS10

DS10

DS11

DS11

DS12

DS12

DS13

DS13

DS14

DS14

DS15

DS15

DS16

DS16

DS17

DS17

DS18

DS18

DS19

DS19

DS20

DS20

DS21

DS21

DS22

DS22

DS23

DS23

DS24

DS24

DS25

DS25

DS26

DS26

DS27

DS27

DS28

DS28

DS29

DS29

DS30

DS30

DS31

DS31

DS32

DS32

DS33

DS33

DS34

DS34

DS35

DS35

DS36

DS36

DS37

DS37

DS38

DS38

DS39

DS39

DS40

DS40

DS41

DS41

DS42

DS42

DS43

DS43

DS44

DS44

DS45

DS45

DS46

DS46

DS47

DS47

DS48

DS48

DS49

DS49

DS50

DS50

DS51

DS51

DS52

DS52

DS53

DS53

DS54

DS54

DS55

DS55

DS56

DS56

DS57

DS57

DS58

DS58

DS59

DS59

DS60

DS60

DS61

DS61

DS62

DS62

DS63

DS63

DS64

DS64

DS65

DS65

DS66

DS66

DS67

DS67

DS68

DS68

DS69

DS69

DS70

DS70

DS71

DS71

DS72

DS72

DS73

DS73

DS74

DS74

DS75

DS75

DS76

DS76

DS77

DS77

DS78

DS78

DS79

DS79

DS80

DS80

DS81

DS81

DS82

DS82

DS83

DS83

DS84

DS84

DS85

DS85

DS86

DS86

DS87

DS87

DS88

DS88

DS89

DS89

DS90

DS90

DS91

DS91

DS92

DS92

DS93

DS93

DS94

DS94

DS95

DS95

DS96

DS96

DS97

DS97

DS98

DS98

DS99

DS99

DS100

DS100

DS101

DS101

DS102

DS102

DS103

DS103

DS104

DS104