
Segments
Digit Strobes
Sol. 1..9 & Sound
Switch Strobes
Lamp Latch Strobes & Lamp Control
Switch Enable
Switch Return
S25..S32
S17..S24
S9..S16
S1..S8
Micro SD shield
WANNENSTECKER-10-ST
EP2CST144C8 dev Board
25LC256/P
74HCT240N
74HCT138N
74HCT139N
74HC4049
74HCT08N
74HC32N
74HC00
Slow active